

NLS-HR2180 UPC-A 0추가



@SETUPE1

Enter Setup



@UPAPRE2

System Character & Country Code



@SETUPE0

**** Exit Setup**